



SYMMONS® Water Dance®

the smart choice™

4-473-LAM Triple Outlet Diverter & Trim Operation & Maintenance Manual



Specification

Water Dance triple outlet diverter and trim shall be made from metal construction. Trim shall be plated in standard polished chrome finish.



Model Numbers

- 4-473-LAM**
Water Dance Triple Outlet Diverter and Trim

Modifications

- STN Satin Nickel finish


Note: Append appropriate -suffix to model number.

Warranty

Limited Lifetime - to the original end purchaser in consumer/residential installations.

5 Years - for industrial/commercial installations. Refer to www.symmons.com/warranty for complete warranty information.


Dimensions



Measurements	
A	5-1/4", 133 mm
B	3-1/4", 83 mm
C	3", 76 mm

Note: Dimensions subject to change without notice.

Parts Breakdown




Replacement Parts

Item	Description	Part Number
A	Set Screw	DF-28-LAM*
B	Lever Handle	
C	Flange	
D	O-ring	
E	Lock Nut	T-19/20-PL*
F	Dome Cover	
K	Diverter Cartridge	RTS-119

***Note:** Append -STN to part number for Satin Nickel finish.


Tools Required for Installation

Phillips Head
Screwdriver




Installation

- 1) Install mounting plate (I) to diverter valve. Secure with two screws (H).




- 2) Attach diverter escutcheon (G) to mounting plate (I).




Note: Tabs should snap into place.

- 3) Install dome cover (F) to valve and secure with lock nut (E).



- 4) Install o-ring (D), flange (C), and lever handle (B) to valve and secure with set screw (A).




Note: Handle should be facing the 6 o'clock position.

Care and Cleaning


Clean finished trim area with a soft cloth using mild soap and water or a non-abrasive cleaner and then quickly rinse with water.

Operation


- 1) Diverter handle facing straight down is for tub spout operation.



- 2) Turn diverter handle counterclockwise 1/2 turn for shower operation.



- 3) Turn diverter handle counterclockwise 3/4 turn for hand shower operation.



Note: Water Dance will run two functions simultaneously when the handle indicator is placed between two function emblems (totaling 6 functions).